

# Updating Groups



To update a group, it usually makes sense to recall that group first. To do this, tap the group, or if you wish to adjust intensities, double tap the group. Then make a new selection of fixtures, or tweak the intensities, and then press **Update** followed by touching the specific group on screen. This updates whichever group you touch on the touch screen. Updating a group will update the contents of that group but will not alter the name of the group.

On FLX, Groups can also be updated using syntax. Make a new selection of fixtures and then type one of the following commands:

**Update** **Group** **1** **4** **Enter**

**Update, Group 14, Enter,**

This updates Group 14

**Update** **Group** touch group

This updates whichever group you touch on the touch screen. You do not need to press the “group” button if the groups window is already displayed.